




FRAME AND CONSOLE PARTS

For Model: DU940QWDB3
Black

UNDERCOUNTER
DISHWASHER



Illus. No.	Part No.	DESCRIPTION
1	3375293	Console (Includes Item 2)
2	3374805	Insert, Console
3	3375556	Control, Electronic
4	3376359	Fuse, Thermal
5	3374762	Switch, Display
7	304231	Screw, 8-18 x 1/2 (5)
8	3374711	Door Frame (Includes Item 26)
9	3368953	Bolt, Latch
10	3369457	Lever, Latch

Illus. No.	Part No.	DESCRIPTION
11	3369325	Switch, (2)
12	3368955	Pin, Switch (2)
13	3376441	Harness and Protector
14	3376405	Elbow, Harness
15	3400803	Screw, 8-32 x 1/4
16	3375473	Cover Timer
17	3374501	Motor, Dual
18	3374777	Door, Sound Absorber


Illus. No.	Part No.	DESCRIPTION
19	3369516	†Panel, Front (Almond/Black)
20	3374010	Retainer, Panel
26	3374716	Channel, Retainer (Also Order Item #20)
27	3373234	Bearing, Spring (2)

†Refer To Dishwasher Replacement Panel Parts List No. 675345.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INNER DOOR PARTS

For Model: DU940QWDB3
Black




Illus. No.	Part No.	DESCRIPTION
1	3371480	Inner Door (Also Order Latch Door Kit 676413)
2	3376066	Latch, Detergent Dispenser
3	3369061	Snap, Detergent Dispenser
4	3369505	Actuator Assembly
5	3369506	Wet Agent, Dispenser
6	3369448	Draw Bar, Electronic
7	3374771	Clip, Console Door Retainer
8	3368999	Spring (Draw Bar)
9	3376404	Lid Assembly
10	300106	Spring, Lid
11	3372028	Pin (Lid Hinge)
12	3371710	Screen, Vent
13	3369512	Wet-Agent Cap Assembly
14	3369155	Seal (Wet-Cap)
15	3369051	Screw (9)
16	3371569	Cover, Drip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB ASSEMBLY PARTS

For Model: DU940QWDB3
Black



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB ASSEMBLY PARTS


For Model: DU940QWDB3
Black

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3375130	Tub Assembly	16	3374621	Water Valve	35	3369193	Panel, Access
2	3369078	Tub, Wheel Assembly (8)	17	304392	Screw, 8-18 x 1/2	36	302868	Screw, 8-18 x 1/2 (4)
3	3368932	Runner (2)	18	3370783	Thermostat, Hi-Limit	37	3369414	Hose, Inlet
4	3374849	Leveler (2)	20	301958	Clamp	39	3374718	Clip, Grounding
5	3370389	Screw, Shoulder (2)	21	3376149	Shield, Thermostat	40	3374765	Sound Shield
6	302819	Wheel (2)	22	3374767	Insulation, Toe & Access Panels	41	3370292	Terminal Box
7	343641	Screw, 10-16 x 1/2 (4)	23	98997	Clip, Harness	42	300068	Cover Assembly, Terminal Box
8	3374719	Plate, Latch	25	304231	Screw, 8-18 x 1/2	43	3369527	†Access Panel (Almond/Black)
9	3374720	Screw	26	3382404	Sound Shield	44	3369526	Spacer, Corrugated
10	3368994	Gasket	28	3374343	Spring, Door (2)	45	3374728	Extension & Clip Assembly
11	3372412	Retainer, Access Panel	29	3369048	Housing, Float Switch	49	3370555	Bracket, Thermostat
12	3369052	Deflector (2)	30	3369067	Switch, Float	51	304666	Retainer, Push (2)
13	3376843	Heater	31	3369049	Cover, Switch Housing	52	3368987	Support, Heater (3)
14	717273	Washer, Rubber (2)	32	3376397	Float & Washer Assembly	53	3371578	Screw, 8-32 x 1/2
15	3369073	Nut (2) (Heater Terminal)	33	717488	Nut	54	3371579	Nut, 8-32
			34	3368942	Toe Panel	55	3370307	Strain Relief
						56	3369138	Screw, 8-18

†Refer To Dishwasher Replacement Panel Parts List No. 675345.

PUMP AND MOTOR PARTS

For Model: DU940QWDB3
Black



PUMP AND MOTOR PARTS

For Model: DU940QWDB3
Black


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9740982	Plate, Perforated (Includes Item 5) (Also Order Item 30) See Note A.	12	3371152	Screw & Seal, 10–32 x 3/4	25	3376157	Base, Pump (Also Order Item 30) See Note A.
2	3367173	Base, Inlet (Includes Items 1 & 5) (Also Order Item 30) See Note A.	13	302711	Seal, Pump Outlet	26	3367197	Support, Pump Mounting (4)
3	9741232	Screw, 8–18 x 5/8	14	3369478	Outlet, Pump (Includes Item 13)	27	3368270	Slinger (See Note A.)
4	302710	Seal, Inlet Base	15	3369482	Check Valve (Includes Item 6)	28	3378053	Motor (Includes Item 27) (Also Order Item 30) See Note A.
5	302709	Ball, Check	16	717000	Gasket, Pump	29	3369331	Screw (4)
6	95080	"O" Ring	17	3376752	Pump & Motor Assembly (Includes Item 16)	30	675505	Pump Seal Kit (Includes Items 4, 12, 13 & 22)
7	302721	Cover, Valve	18	302707	Bushing, Grind	31	303918	Tool, Pump Centering
8	302738	Valve Stem Kit (Includes Items 12, 13 & 22) See Note A.	19	302718	Chopper Kit (Also Order Item 30) See Note A.	32	356138	Clamp, Hose
9	303883	Separator Assembly (Includes Items 12, 13 & 22) See Note A.	20	302705	Sleeve, Drain Impeller	33	3368781	Hose, Drain
10	3400001	Screw, 8–16 x 1–5/8 (4)	21	9741321	Screw, 8–18 x 5/8	34	3371748	Cap, Drain
11	3376402	Impeller, Wash (Includes Items 12 & 13)	22	302704	Seal, Drain Cover	35	3374757	Shaft, Absorber
			23	302723	Cover, Drain (Also Order Item 30) See Note A.	36	3374756	Weight, Absorber
			24	303539	Impeller, Drain Kit (Also Order Item 30) See Note A.	37	3376722	Thermostat
						38	3376723	Seal, O–Ring
						39	3376358	Retainer, Thermostat

NOTE A:

Pump Centering Tool Required
For Pump Re–Assembling—
Order Item 31.

DISHRACK PARTS

For Model: DU940QWDB3
Black




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISHRACK PARTS

For Model: DU940QWDB3
Black

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	303722	Clip	OPTIONAL PARTS NOT INCLUDED					
2	3368290	Support, Arm (Also Order Items 1 & 8)	PAINT, TOUCH-UP (1/2oz.)					DISHRACK REPAIR
3	3368300	Spray Arm, Upper (Also Order Items 1 & 8)						675576 Vinyl Touch-Up (Blue)
4	3368006	Bumper (2)						675677 Tine Tip Repair Kit (Blue— Enough For Two Complete Dishracks)
5	300848	Tower, Pressure	PAINT, PRESSURIZED SPRAY (13 oz.)					676453 Vinyl Touch-Up (White)
6	3376961	Wheel & Transport Assembly (4)						675679 Tine Tip Repair Kit (White— Enough For Two Complete Dishracks)
7	3375100	Dishrack, Lower (Includes Items 4 & 6)						676455 Vinyl Touch-Up (Grey)
8	3374702	Support, Lock Spray Arm	PAINT, TOUCH-UP (1 qt.)					676458 Tine Tip Repair Kit (Grey— Enough For Two Complete Dishracks)
9	3369488	Silverware Basket Assembly						LITERATURE PARTS
10	3369485	Cover, Basket	ACCESSORY PARTS					LIT3369679 Instructions, Installation
11	300845	End Cap (Front or Rear)						LIT3367007 Instructions, Installation (Supplement) (Locating Your Water Supply)
12	3369071	Track						LIT3373484 Energy Guide
13	301077	Screw (8)						LIT3373753 Guide, Use & Care
14	3369980	Housing, Adjuster (2)						LIT3376445 Tech Sheet
15	3369981	Worm (2)						
16	3369979	Plate, Mtg. (2) (Adjuster)						
17		Arm Assembly (Includes Item 15)						
	3369977	Right Side						
	3369973	Left Side						
18	3375116	Dishrack, Upper						
19	717528	Trim, Basket						
20	300086	Handle, Basket						
21	3369494	Basket, Utensil						
22	3369347	Sprayarm, Lower						
23	3367910	Cap, Nozzle						
24	719576	Bearing, Nozzle						
25	3374701	Stop, Track (2)						
26	3368629	Retainer, Flexrow						
27	3375124	Flexrow						
								Following May Be Purchased
								DO-IT-YOURSELF REPAIR MANUALS
								LIT0677967 Do-It Yourself, Manual

MISCELLANEOUS PARTS



Illus. No.	Part No.	DESCRIPTION
1	3369816	Miscellaneous Parts Bag (Includes 2 Screws & 2 Hose Clamps)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST